

**FAQs:**

[Permits to Fly, General Aviation](#)

**Question:**

**When do I need a Permit to Fly?**

**Answer:**

A Permit to Fly (PtF) may be needed when your aircraft does not meet, or has not yet been shown to meet, the applicable airworthiness requirements and, as a result, cannot hold or be issued a valid Certificate of Airworthiness (CofA) or Restricted CofA, although it is capable of safe flight under defined conditions. In this case, a PtF may be obtained when the aircraft needs to fly for various possible flight purposes, as listed under Part 21.A.701 and related Guidance Material, subject to approval of associated Flight Conditions (FC).

More information on PtF and FC is published on the EASA website and in the EASA procedure PR.CAP.00125. Please click [here](#). You may also wish to read the other [FAQ n. 21919](#).

Also note that the responsible EASA Member State of Registry can also grant an exemption to allow an aircraft to fly without a valid (R)CofA under the provisions of Article 71 of the Basic Regulation ([Regulation \(EU\) 2018/1139](#)), if it finds that the conditions of this article are met.

**Last updated:**

03/03/2025

**Link:**

<https://www.easa.europa.eu/hr/faq/19390>