

## Recognising a Galaxy Note 7 device

The following information is provided to assist aviation personnel (check-in staff, cabin crew) in recognising a Galaxy Note 7 device and to avoid confusion with other Samsung devices.

Note7 has an **S-Pen** and is **curved on both sides**.



Only Samsung Galaxy **Note** models have a **stylus pen (S-Pen)**



Note7 is easy to distinguish from earlier Samsung Galaxy Note devices

Note7 differs from prior Note models in at least **three** ways:

- 1) the **S-Pen** has a “**spring**” function i.e. when you touch its tip, it “springs” out;
- 2) it has a **round** charge port – while prior Note models have a **hexagon** charge port
- 3) Note7 is dual **curved** on the front and back



## Other ways to distinguish Note 7 from earlier Samsung Galaxy Note devices

- On Note II models, shape of the **'flash'** next to the camera is different from that on Note7

Note II



Note 7



## Other ways to distinguish Note 7 from earlier Samsung Galaxy Note devices

- On Note III models, **'flash'** is located **under** the camera, while on Note7 it is **next** to the camera

Note III



Note 7



## Other ways to distinguish Note 7 from earlier Samsung Galaxy Note devices

- On Note 4 models, **'flash'** is located **under** the camera, while on Note7 it is **next** to the camera

Note 4



Note 7

